

Code No.	Reflector	f-stop	decimal values Canon / Nikon
5050	14"	11	(11)
9601	12"	8-1/10	(8,3)
5060	9"-S	5,6- 8/10	(7,5)
5061	9"-M	5,6- 6/10	(7,0)
5062	9"-L	5,6- 4/10	(6,5)
5059	9"-SW	4,0- 5/10	(4,8)
504	7"	4,0- 6/10	(5,0)
87	umbrella	4,0- 2/10	(4,3)
9201	Accent Tube	2,8	(2,8)
8607	Beauty Dish W with cap	2,8- 4/10	(3,3)
8607 u. 507	Beauty Dish W with 7" honey comb	2,8- 7/10	(3,6)
4000150	Octaform 150	2,8 -4/10	(3,3)
4000150	Octa150 only inner diffusor	4 -1/10	(4,2)
4000150	Octa150 without diffusor	4 -5/10	(4,8)
3410	Ringflash 3000-XS	4 -4/10	(4,6)